

Screened Bottom Board Assembly Instructions

Materials:

| Qty | Width | Length | Description |
|-----|-------|--------|--|
| 2 | 1 ½ " | 21 ¾" | Side pieces w/ one 45° angle |
| 1 | 1 ½ " | 16 ¼" | Back piece w/ two 45° angles |
| 1 | 3 ½" | 16 ¼" | Alighting board |
| 2 | 7/8 " | 20 ¾" | Side strips to hold screen down w/ one 45° angle |
| 1 | 7/8" | 16 ¼" | Back strip to hold screen down w/ two 45° angles |
| 1 | 1/8" | | Mesh screen |

What you will need:

- Either 7/16" x 2" to 2 ½ " staples, 6d or 8d box nails, or 2" screws. (for general assembly – **If using screws, pre-drill holes**)
- Either 1 ½" to 2" staples or 3d to 4d finish or box nails to nail side and back strips.
- Heavy Duty Hand Stapler with 3/8" heavy duty staples for securing screen at entrance.

General Comments before you begin:

- Glue is recommended for all joints throughout assembly
- Assembly should be done on a flat level surface.
- If you have any problems understanding the instructions feel free to give us a call at (405)600-7200.

